



Plan View


30'

20'



SETUP INSTRUCTIONS



 = 1 sq foot

General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. **Heat and UV exposure will warp and fade components.**
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection



Extrusion & Lock Connection



Engaged Lock



WARNING



DO NOT USE POWER TOOLS



LADDERS OR LIFTS
MAY BE REQUIRED



ALL CONNECTIONS MUST
BE TIGHTLY SECURED




CRATE PACKING

Item	Qty.	Description
4	1	96" h S44 Vertical Extrusion w/ Door Stop
5,6,7	1,1,1	96" h S44 Vertical Extrusion
8,9,10	1,1,1	96" h S44 Vertical Extrusion
11	1	96" h S44 Vertical Extrusion w/ Door Hinge
12/12A	3/3	22.126" w Z45 Horizontal Extrusion
13/13A	1/1	22.5" w Z45 Horizontal Extrusion
14/14A	1/1	22.5" w Z45 Horizontal Extrusion
15/15A	3/3	22.126" w Z45 Horizontal Extrusion
--	1	Door Threshold


Steps:

Note: If necessary, remove PR37 conduit from verticals [4,7] before starting assembly. Do not remove door stop.

- 1) Attach lower horizontals [12,14,15] & Door Threshold between verticals [4,5,6,7,8,9,10,11] as shown, & connect horizontal [13] between verticals [4,11]. See **Door Threshold Attachment** detail.
- 2) Slide Infills between verticals; secure with upper horizontals [12A,13A,14A,15A].



When assembled




Item	Qty.	Description
8A,11A	1,1	62.047”h S44 Vertical Extrusion w/ PR63
22/22A	1/1	70”w Z45 Horizontal Extrusion
23	4	2.5”h Z45 Vertical Extrusion

Steps:

- 1) Attach upper verticals [8A,11A] to top of lower verticals [8,11] as shown.
- 2) Connect horizontals [22,22A] between verticals [8A,11A].
- 3) Attach verticals [23] to top of upper horizontal [22A].

S44 Connector





Connector Piece

Screws

Slide extrusion over connector and rest on lower vertical; secure with screws.

****To prevent product loss, Keep all screws attached to connector piece after disassembling**



When assembled

AERO


Using Your Setup Instructions

The Aero Setup Instructions are created specifically for your configuration. The instructions include an exploded view of the frame which is sequentially labeled. We encourage you to review the instructions before attempting to assemble your exhibit.



Connections are kept very simple; no tools required. Everything assembles with push-button connectors.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.




Connections are made by holding the button down and sliding the red tube into opposing tube until button locks into the hole of the opposing tube. To disassemble, push button and pull or twist extrusions apart.



Steps:

- 1) Assemble Aero frame parts together in numerical order, as shown.
- 2) Attach pillowcase graphic to assembled frame.
- 3) Attach frame to Base Plates.


Base Plate



Steps:

- 1) Attach Large Aero Ring to top of verticals [8A,11A] using Aero mounts. See [Aero Frame Attachment](#) detail.

*** Aero Frame Attachment**



Turn to tighten

Aero Mount


Connector

S44








Set screw

Attach connector to top of vertical extrusion; tighten set screws to secure.

Insert Aero Mount into threaded hole in top of connector; turn barrel clockwise to tighten in place.



- Steps:
- 1) Attach Header Graphics to front & back of upper assembly, using screw caps.
See [Header-to-S44 Attachment](#) & [Header-to-Z45 Attachment](#) details.
 - 2) Install Lights to top of verticals [23]. See [Light Connection](#) detail.
 - 3) Attach PR63 conduit to verticals [8A, 11A] for wire management.
See [PR63 Attachment](#) detail.
 - 4) Install Monitor Mount to verticals [9, 10]. See [Monitor Mount Attachment](#) detail.
 - 5) Connect Door to Vertical [11]. See [Door Attachment](#) detail.



AERO


Using Your Setup Instructions

The Aero Setup Instructions are created specifically for your configuration. The instructions include an exploded view of the frame which is sequentially labeled. We encourage you to review the instructions before attempting to assemble your exhibit.


Connections are kept very simple; no tools required. Everything assembles with push-button connectors.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.





Connections are made by holding the button down and sliding the red tube into opposing tube until button locks into the hole of the opposing tube. To disassemble, push button and pull or twist extrusions apart.



Steps:

- 1) Assemble Aero frame parts together in numerical order, as shown.
- 2) Attach pillowcase graphic to assembled frame.



AERO


Using Your Setup Instructions

The Aero Setup Instructions are created specifically for your configuration. The instructions include an exploded view of the frame which is sequentially labeled. We encourage you to review the instructions before attempting to assemble your exhibit.


Connections are kept very simple; no tools required. Everything assembles with push-button connectors.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.





Connections are made by holding the button down and sliding the red tube into opposing tube until button locks into the hole of the opposing tube. To disassemble, push button and pull or twist extrusions apart.






Steps:

- 1) Assemble Aero frame parts together in numerical order, as shown.
- 2) Attach pillowcase graphic to assembled frame.






Item	Qty.	Description
1	4	66" h S40 Vertical Extrusion
2	4	66" h S40 Vertical Extrusion
3	4	36" h S40 Vertical Extrusion w/ Door Hinge
4	4	36" h S40 Vertical Extrusion w/ Door Stop
5	4	40.975" S40 curved Vertical Extrusion
6	4	40.975" S40 curved Vertical Extrusion
7	4	5.24" w Z32 Horizontal Extrusion w/ mitred end
8	4	5.24" w Z32 Horizontal Extrusion w/ mitred end
9/9A/9B	4/4/4	18.5" w S40 Horizontal Extrusion
10/10A	4/4	18.5" w S40 Horizontal Extrusion
11/11A	4/4	18.5" w S40 Horizontal Extrusion
12	4	21.02" x 4.5" Mounting Plate



Steps:

- 1) Connect curved extrusions [5,6] between verticals [1,2,3,4] using horizontals [7,8].
- 2) Attach lower horizontal [9] between verticals [1,2]; connect lower horizontal [10] between verticals [3,4].
- 3) Attach Door between verticals [3,4]. See **Door Attachment** detail.
- 4) Slide lower **infills** between verticals & curved extrusions as shown; secure with horizontals [9A,10A,11,11A].
- 5) Place **Shelf** inside assembly.
- 6) Place **Counter Top** onto assembly, sliding over verticals [1,2].
- 7) Slide upper **infill** between verticals [1,2]; secure with upper horizontal [9B].
- 8) Attach Mounting Plate [12] to verticals [1,2]; & install Monitor Mount. See **Monitor Mount Attachment** detail.



Repeat steps 1 through 8 for other three workstations.




Steps:

- 1) Slide assembled Kiosks over Aero frame.
- 2) Connect Aero Frame to Kiosks using custom bracket.
See **Custom Bracket Connection** detail.

Repeat steps 1 & 2 for other Aero Frame.




When assembled
QTY 2




Item	Qty.	Description
1	1	37.5" h Vertical Extrusion
2	1	37.5" h Vertical Extrusion
3	1	37.5" h Vertical Extrusion
4	1	37.5" h Vertical Extrusion
5/5A	2/2	18.5" w Horizontal Extrusion
6/6A/6B	2/1/2	46" w Horizontal Extrusion
7	1	33.917" h Vertical Extrusion

Steps:


- 1) Connect lower Horizontals [5,6] between Verticals [1,2,3,4].
- 2) Attach Vertical [7] to lower Horizontal [6].
- 3) Slide **Infills** between Verticals [1,2] [2,3] and [3,4].
- 4) Connect Horizontal [6A] between Verticals [2,3].
- 5) Place **Infill** on top of Horizontal [6A].
- 6) Connect assembled Counter frame to Floor.
- 7) Connect Doors to Vertical Extrusions [1] & [4].
See **Door Attachment** detail.
- 8) Connect upper Horizontals [5A] & [6B] between Verticals and on top of Infills and Doors.





When assembled
(Front View)



Back View



Back View



Back View

AERO


Using Your Setup Instructions

The Aero Setup Instructions are created specifically for your configuration. The instructions include an exploded view of the frame which is sequentially labeled. We encourage you to review the instructions before attempting to assemble your exhibit.



Connections are kept very simple; no tools required. Everything assembles with push-button connectors.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



Connections are made by holding the button down and sliding the red tube into opposing tube until button locks into the hole of the opposing tube. To disassemble, push button and pull or twist extrusions apart.






Steps:

- 1) Connect Aero frame parts in alphabetical order as shown.
- 2) Apply pillowcase graphic to each frame.





Steps:

- 1) Slide Aero Frame assemblies into the groove of front Verticals [2] & [3].
- 2) Attach front Sintra graphic to Verticals [2,3], using Velcro.
- 3) Place Counter Top on top of assembled Base. See **Counter Top Attachment** detail.




Steps:

- 1) Attach base to curved stand, using bolts.
- 2) Attach square plate to stand, using bolts.
- NOTE: Square plate must rotate to left and right before installing clamshell.*
- 3) Attach clamshell to square plate using hex nuts.
- 4) Insert iPad and feed wire through hole as shown in detail.



QTY 2




Wire Management for iPad



Attach iPad Cord to supplied USB Extension Cord. Feed USB Cord through top hole of Post, then out bottom hole of Post. Connect to Power.

Optional Cover for Home Button



- 1) Remove foam lining from inside bottom of Clamshell.
- 2) Attach Home Button Shield with double-sided tape to inside of Clamshell, keeping top of shield flush with Clamshell opening.

NOTE: This is a permanent fix and can't be easily removed.

- Tools Required:
- 1) Hex Tool
 - 2) Pliers

